

CHE654 – Plant Design Project #3 Semester 1, 2024

DESIGN OF ISOPRENE AND ALDEHYDES PRODUCTION PROCESSES FROM PROPYLENE

Courtesy of National Programme on Technology Enhanced Learning (NPTEL)

Introduction

Isoprene, or 2-methyl-1,3-butadiene, is a common organic compound with the formula CH2=C(CH3)−CH=CH2. In its pure form it is a colorless volatile liquid. Isoprene is produced by many plants and animals (including humans) and its polymers are the main component of natural rubber. C. G. Williams named the compound in 1860 after obtaining it from thermal decomposition (pyrolysis) of natural rubber; he correctly deduced the empirical formula C_5H_8 . Isoprene can be prepared using propylene and is an important commodity for polymerization reactions and products.

Oxoprocessing involves reaction between olefins and synthesis gas at high pressure to yield aldehydes. Olefin, also called alkene, is a compound made up of hydrogen and carbon that contains one or more pairs of carbon atoms linked by a double bond. Olefins are examples of unsaturated hydrocarbons (compounds that contain only hydrogen and carbon and at least one double or triple bond). The aldehydes can be subsequently subjected to hydrolysis to obtain short as well as long chain alcohols.

The plant where you are employed has been buying isoprene and aldehydes as feedstocks. Management is considering manufacturing the two compounds rather than purchasing it to increase profits. Someone has made a preliminary sketch for such a process and has submitted to the engineering department for consideration. Your group is assigned the problem of evaluating the sketch and recommending improvements in the preliminary design. Your job is to analyze simplified isoprene and aldehydes production processes, to suggest profitable operating conditions, and to write a final report summarizing your findings. Note that optimization is NOT required in this design project.

Isoprene Manufacture

Reactions

- \Box Isoprene is manufacture from propylene using three consecutive reactions. These are:
	- \triangleright Dimerization of propylene to obtain 2-methyl-1-pentene

$$
\begin{array}{ccc}\n & & \text{CH}_3 \\
\text{2.H}_2\text{C}=\text{CH} & \text{CH}_3 & \xrightarrow{\text{dimension}} & & | \\
 & & \text{H}_2\text{C}=\text{C} & \text{CH}_2-\text{CH}_2-\text{CH}_3 \\
 & & \text{(propylene)} & & \text{(2-methyl-1-pentene)}\n\end{array}
$$

 \triangleright Isomerization of 2-methyl-1-pentene to obtain 2-methyl-2-pentene

CH₃ CH₃
\n
$$
H_2C = C - CH_2 - CH_2 - CH_3 \xrightarrow{\text{isomerization}} H_3C - C = CH - CH_2 - CH_3
$$
\n(2-methyl-1-pentene) (2-methyl-2-pentene)

 \triangleright Pyrolysis of 2-methyl-2-pentene to obtain isoprene along with methane as a side – product.

CH₃ $CH₃$ $H_3C = C - CH$ $- CH_2$ $- CH_3$ $\stackrel{\text{pyrolysis}}{\longrightarrow} CH_2$ $\stackrel{\text{pycolysis}}{\longrightarrow} CH_2$ $\stackrel{\text{pycolysis}}{\longrightarrow} CH_2$ CH_2 $+ CH_1$ \mathbf{L} (2-methyl-2-pentene) (isoprene) (methane)

- \Box Since three reactions are involved that have distinct operating conditions as well as catalyst requirements, the process involves a series of reactor-separator-recycle networks.
- \Box We therefore, consider presenting all these cases separately so that the process can be well understood.

Dimerization reaction

- Catalyst is tripropyl aluminium.
- A solvent carrier is used that enables the recovery of the catalyst from the product stream.
- \div Operating conditions are 150 200 °C and 200 atm.

Isomerization reaction

- The reaction requires an acid catalyst on porous carrier.
- \div Operating conditions are 150 300 °C and normal pressure conditions.

Pyrolysis reaction

- HBr catalyst is used.
- \div Operating conditions are 650 800 °C and normal pressure.

Process Technology

The figure below shows a flowsheet of isoprene manufacture from propylene.

The process technology consists of three major blocks, namely

- 1. Dimerization-separator-recycle network (DSR)
- 2. Isomerization-separator-recycle network (ISR)
- 3. Pyrolysis-separator-recycle network (PSR)

DSR network

- \Box Propylene feed is mixed along with unreacted propylene (recovered in a distillation column in the DSR) to enter a mixer.
- \Box The mixer is fed with tripropyl aluminium catalyst (this catalyst is in liquid phase).
- \Box The mixture is compressed to about 200 atm. At these conditions, the mixture is in the liquid phase.
- \Box The liquid phase dimerization feed enters the dimerization reactor.
- \Box The dimerization reactor is a CSTR with dowtherm fluid circulated in the cooling jacket to remove the heat generated from the exothermic reaction.
- \Box After the reaction, the liquid stream is subjected to flash operation. From the flash tower a vapor and liquid stream are produced. The liquid stream consists of the catalyst + solvent whereas the vapor stream consists of the unreacted propylene, light ends and the product formed.
- \Box The liquid stream from the flash tower is recycled back to the dimerization CSTR.
- \Box The vapor stream enters a fractionation tower that produces light ends such as C_1-C_2 as the top product. The bottom product consists of propylene and dimerized product i.e., 2 methyl-1-pentene.
- \Box This product is subjected to again fractionator in a separate tower to obtain 2-methyl-1pentene as the bottom product and propylene as the top product. The top propylene product is then recycled back to mix with the fresh propylene feed stock and enter the mixer unit.

ISR network

- 2-methyl-1-pentene enters an isomerization reactor which consists of acid catalyst (on porous carrier).
- \Box The isomerization reactor is a packed bed reactor operated at desired operating temperature.
- \Box After the reaction, the products are sent to a fractionator that separates unreacted 2-methyl-1-pentene from the isomerized product i.e., 2-methyl-2-pentene.

PSR network

- 2-methyl-2-pentene enters a pyrolysis furnace.
- \Box Steam is also mixed with the organic vapors so as to quickly facilitate cracking in the pyrolysis furnace.
- \Box The furnace is a shell and tube arrangement with the reactants entering the tubes and the hot flue gases enter the shell.
- \Box HBr catalyst also enters the tubes of the pyrolysis furnace.
- \Box After reaction, the product gases (HBr + product + reactant) are taken out and are quenched with a solvent in a quench tower. The quenching then produces a gas liquid mixture which is sent to a phase separator unit. The liquid stream from the phase separator stream consists of HBr + solvent and this is sent for quenching.
- \Box Fresh HBr can be generated from the HBr + solvent obtained from the phase separator.
- \Box The gas fraction from the phase separator enters a C₁ tower that separates fuel gas and other light ends as a top product.

 \Box The bottom product from this tower consists of polymeric compounds and isoprene is fed to a purification tower to fractionate isoprene from the polymeric compounds.

Technical Questions

1. What solvent can be used in the quenching process?

Ans: HBr can be readily absorbed into water. Therefore, water can be used as a solvent in the quenching process. There is a patent available where it says that acetone can be used to recover HBr. More details can be obtained of this patent by furthering the search on the patent data base using the internet.

2. In the process flow sheet given the HBr recovery is not shown. Do you think the flow sheet is correct? Suggest any modifications to the flow sheet?

Ans: Yes, the flowsheet has an error in that sense. The flowsheet should give a section for HBr recovery where HBr is recovered in the quenched solvent and the fresh HBr gas is allowed to enter the pyrolysis furnace along with the steam. In such case, one has to put an additional HBr stripper which can strip HBr from the HBr + solvent stream that is fed to this unit and the HBr can be sent to the pyrolysis unit. The fresh solvent can be then sent to a cooler and sent to the quench tower and the existing recycle stream to the quenching tower will not be there. Instead, this stream will go to the stripper as a feed stream.

3. Can we not do heat integration partially for the pyrolysis furnace with the vapor products?

Ans: HBr is very corrosive and therefore, if we go for heat integration using the vapor product, then the shelf life of the pyrolysis furnace will be minimized. Therefore, better we don't go for heat integration in this way.

4. Is a purge stream required in the process flowsheet shown for the quench fluid + HBr mixture?

Ans: Yes, and this is not shown in the process flow sheet. Some impurities such as some light ends that might dissolve with the solvent will have to be purged, if not these can cause coking problems and can cause unwanted organics in the pyrolysis furnace reactor.

5. What sort of regeneration would you recommend for the isomerization catalyst?

Ans: Heating the catalyst in oxygen or air to remove coke would be beneficial to regain the activity of the isomerization catalytic bed.

6. Suggest what changes will be there in the process flow sheet if pure propylene instead of a mixture of propylene, propane and C_1 - C_2 components is used?

Ans: The C_1-C_2 tower and C_3 towers can be replaced with a single tower after flash unit. This new unit will separate all light ends in trace amounts in a single tower with middle product being 2-methyl-1-pentene and heavy ends as bottom product. Therefore, a complex distillation unit arrangement would be at the maximum required replacing three distillation columns in series.

Oxo Processing of Olefins

Reactions

In an oxo process, we react an olefin with synthesis gas to obtain aldehyde i.e.,

Olefin + $CO + H_2 \rightarrow$ Aldehyde.

This reaction is called as hydroformylation.

Dimerization (Option): Alternatively, if desired, the aldehyde dimerization reaction can be also carried out. In that case, two molecules of aldehydes react to obtain a higher order aldehyde.

In short, the oxo processing can be targeted to generate both short chain and long chain aldehydes.

Hydrogenation (Option): When short and long chain aldehydes are subjected to hydrogenation then one can produce alcohol or an acid.

Oxygenation (Option): When short and long chain aldehydes are subjected to reaction with oxygen or air, then acids can be formed.

Thus the oxo processing of olefins can generate.

- 1. Short and long chain aldehydes
- 2. Short and long chain alcohols
- 3. Short and long chain acids

Therefore, gases can be converted into these useful products. Various applications of these compounds include plasticizers for polymerization reactions, solvents, detergent raw materials etc.

The process will be demonstrated for propylene but can be suitably extended to other alkenes such as butylenes or ethylene.

Operating Conditions

Addition reaction

Catalyst: Cobalt naphthanate.

- **O** Operating conditions: Pressure of $100 400$ atm and temperature of $100 200$ °C.
- \Box The reaction is exothermic.
- Reaction occurs on a packed bed reactor where the packed bed acts as a surface to deposit the catalyst i.e., cobalt.
- \Box In due course of reaction, the cobalt enters the product stream and therefore needs to be recovered.

Dimerization reaction

- □ Catalyst: Zinc salt.
- Operating conditions: Higher pressure and moderate temperatures.

Hydrogenation reaction

- **Q** Catalyst: Nickel.
- □ Operating conditions: 100 atm and 150 °C.

Process Technology

The figure below shows a simplified flowsheet of oxo processing of olefins.

To produce alcohols, the process consists of four basic steps namely hydroformylation, decatalization, hydrogenation and a separation network.

Hydroformylation

- \Box Propylene and synthesis gas are separately compressed and sent to the hydroformylation reactor along with the Cobalt catalyst (i.e., Cobalt napthanate).
- \Box The concentration of Cobalt Naphthenate is about 1 wt% Cobalt in the feed mixture.
- During the reaction at the existing operating conditions some Cobalt gets deposited on the porous carrier.
- \Box Since the reaction is highly exothermic, there shall be cooling. To do so, cold liquid stream obtained after phase separation is recycled.
- \Box The product liquid from the reactor is sent to a partial condenser followed by phase separator. The phase separator separates the unreacted synthesis gas (by considering the propylene in the feed stock to be limiting) and the liquid product stream. The liquid product stream is partially recycled back to the reactor to serve as a diluent to control the temperatures in the packed bed reactor.
- \Box The liquid product stream consists of dissolved cobalt and hence it needs to be extracted back as the salt to enter the hydroformylation reactor.
- \Box Therefore, the product stream is partially sent to the Decatalization process so as to remove the catalyst from the stream.

Decatalization

- \Box The liquid product from the phase separator is sent to a packed bed unit where it is mixed along with steam at 180°C at a pressure of 20 atm.
- \Box At this condition, Cobalt salt in the hydrocarbon liquid gets transferred to the porous carrier as cobalt oxide.
- \Box For reuse, the cobalt oxide on the porous carrier is treated with acid to generate the cobalt naphthanate and this will be sent back to the hydroformylation reactor.
- \Box The vapors generated from decatalization unit consist of the aldehyde products. These are sent to the hydrogenation unit next to convert aldehydes to alcohols.

Hydrogenation

- \Box The aldehyde product vapors are fed to a nickel catalytic bed reactor.
- \Box Hydrogen is also fed to the reactor at about 150 °C and 100 atm.
- After reaction, butanols and other alcohols are sent to a separator network.

Separator network

 \Box The separator network consists of several fractionators in series.

 \Box The fractionators in series produce light ends and heavy ends in addition to the desired product i.e., butanol.

Technical Questions

1. The flow sheet presented corresponds to production of butanol from propylene. If higher order alcohols are desired, how does the flow sheet get modified?

Ans: An additional unit process entitled "Dimerization" will be part of the flow sheet. In such case, the cold liquid stream from the phase separator enters the dimerization reactor to convert lower order aldehydes to higher order aldehydes.

2. Suppose we wish to produce both short chain and long chain aldehydes and do not wish to produce alcohols then how does the process topology change?

Ans: When both short and long chain aldehydes are required, then we have to allow the cold liquid from the phase separator to enter the dimerization reactor partially only. Then the dimerization reactor product as well as the phase separator stream enter the decatalization unit to achieve catalyst recovery.

3. Can the hydroformylation reactor be used as a dimerization reactor as well?

Ans: Yes, in this way, we can produce all desired products in a single reactor and we can avoid dimerization reactor. But the balance between cobalt and zinc catalysts will dictate the product composition palette.

4. Why high pressure is required in the hydroformylation reactor?

Ans: Higher pressures enable the formation of a complex between Cobalt and the hydrocarbons participating in the reaction. If higher pressure is not existent, the cobalt complex can decompose and this does not favour higher conversions.

5. Can the series of distillation columns in the separator network be replaced with a complex distillation column?

Ans: Yes, this is possible and this is recommended as the light end and heavy end products are not significant in make and the aldehyde products are the actual products that are desired. A complex distillation reduces the number of columns required, enables complex interaction between both vapor and liquid streams and facilitates drastic reduction in the cost.

Design of Heat Exchangers

A detailed design of at least one heat exchnager in the process is required for base-case conditions. For this heat exchanger design, the following information should be provided:

- Diameter of shell
- Number of tube and shell passes
- Number of tubes per pass
- Tube pitch and arrangement (triangular/square/..)
- Number of shell-side baffles, if any, and their arrangement (spacing, pitch, type)
- Diameter, tube-wall thickness, shell-wall thickness, and length of tubes
- Calculation of both shell- and tube-side film heat transfer coefficients
- Calculation of overall heat transfer coefficient (you may assume that there is no fouling on either side of the exchanger)
- Heat transfer area of the exchanger
- Shell-side and tube-side pressure drops (calculated, not estimated)
- Materials of construction
- Approximate cost of the exchanger

A detailed sketch of the exchanger should be included along with a set of comprehensive calculations in an appendix for the design of the heat exchanger. You should use ASPEN Exchanger Design $\&$ Rating (EDR) in the ASPEN Plus simulator to carry out the detailed design.

Economic Analysis

When evaluating alternative cases, you should carry out an economic evaluation and profitability analysis based on a number of economic criteria such as payback period, internal rate of return, and cash flow analysis. In addition, the following objective function should be used. It is the equivalent annual operating cost (EAOC), and is defined as

 $E A O C = -$ (product value – feed cost – other operating costs – capital cost annuity)

A negative EAOC means there is a profit. It is desirable to minimize the EAOC; i.e., a large negative EAOC is very desirable, although you are not being asked to carry out optimization.

The costs for cumene (the product) and benzene (the feed) should be obtained from the Chemical Marketing Reporter, which is in the Evansdale Library. The "impure" propylene feed is \$0.095/lb.

The capital cost annuity is an *annual* cost (like a car payment) associated with the *one-time*, fixed cost of plant construction. The capital cost annuity is defined as follows:

capital cost annuity =
$$
FCI \frac{i(1+i)^n}{(1+i)^n - 1}
$$

where FCI is the installed cost of all equipment; i is the interest rate, $i = 0.15$; and n is the plant life for accounting purposes, $n = 10$.

For detailed sizing, costing, and economic evaluation including profitability analysis, you may use the Aspen Process Economic Analyzer (formerly Aspen Icarus Process Evaluator) in Aspen Plus. However, it is also a good idea to independently verify the final numbers based on other sources such as cost data given below.

Other Information

You should assume that a year equals 8,000 hours. This is about 330 days, which allows for periodic shut-down and maintenance.

Final Comments

As with any open-ended problem; i.e., a problem with no single correct answer, the problem statement above is deliberately vague. You may need to fill in some missing data by doing a literature search, Internets search, or making assumptions. The possibility exists that as you work on this problem, your questions will require revisions and/or clarifications of the problem statement. You should be aware that these revisions/clarifications may be forthcoming.

Moreover, in some areas (e.g. sizing/costing) you are given more data and information than what is needed. You must exercise engineering judgment and decide what data to use. Also you should also seek additional data from the literature or Internet to verify some of the data, e.g. the prices of products and raw materials.

References

- 1. Dryden C. E., Outlines of Chemical Technology, East-West Press, 2008.
- 2. Kirk R. E., Othmer D. F., Encyclopedia of Chemical Technology, John Wiley and Sons, 1999-2012.